INSTRUCTION MANUAL

TOWER FAN: SF-1522



PLEASE READ BEFORE USE AND SAVE THIS MANUAL

IMPORTANT SAFETY INSTRUCTIONS

READ AND SAVE THESE SAFETY INSTRUCTIONS BEFORE USE

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1、 Use this fan only as described in this manual. Other use not recommended may cause fire, electric shock or injury to persons.

2、 This product is intended for household use ONLY and not for commercial, industrial or outdoor use.

3、 To protect against electric shock: do not place fan on windowsills, immerse unit, plug or cord in water or spray with liquids.

4、 This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of shock, this plug is intended to fit only one way in a polarized outlet. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. DO NOT attempt to defeat this safety feature.

5、 Close supervision is necessary when any appliance is used by or near children.

6、 Turn the fan OFF and unplug the fan from the outlet when not in use, when moving the fan from one location to another and before cleaning.

7、 To disconnect the fan, first turn the unit OFF, grip the plug and pull it from the wall outlet. Never pull the plug by the cord.

8、 Do not operate the fan in the presence of explosive and/or flammable fumes.

9、 Do not place the fan or any parts near an open flame, cooking or other heating appliance.

10、 Do not operate fan with a damaged cord or plug, or if the product malfunctions, or dropped and damaged in any manner (see warranty).

11、 Avoid contact with moving fan parts.

12、 The use of attachments not recommended by the manufacturer may be hazardous.

13、 Place the fan on a dry level surface.

14、 Do not hang or mount fan on a wall or ceiling.

15、 Do not operate if the fan housing is damaged.

16、 A loose fit between the AC outlet (receptacle) and plug may cause overheating and a distortion of the plug. Contact a qualified electrician to replace loose or worn outlet.

WARNING: To reduce the risk of fire and electric shock, do not use this fan with any solid-state speed control device.

ASSEMBLY INSTRUCTIONS

Do not use this fan before assembling the base.



PARTS IDENTIFICATION

Fig.1 Control panel



FAN OPERATION

Plug into any AC 120V, 60Hz source, insure that the plug fits securely into the socket.
Your fan is equipped with 4-fan speed buttons, a timer dial, an OSC switch and a night light switch.

1) Speed control buttons:

BUTTON	FUNCTION
OFF	OFF
L	low speed
M	medium speed
H	high speed

2) Timer Switch:

- Turn dial clock-wise to set desired time of operation (maximum 2 hours).
- To run fan continuously, point dial position to **ON**.
- Pressing the OFF (0) button will turn fan and timer off.

3) OSC (oscillation) switch:

- To activate, press the OSC switch once while fan is operating.
- Press again to turn the oscillation feature off.

4) Night light switch:

- **ON** position: turn on
- **OFF** position: turn off

CLEANING AND STORAGE

- Turn off power and unplug the fan before cleaning.
- Use only a soft, damp cloth to gently wipe the outer surfaces.
- To clean between the grilles, we recommend using a pipe cleaner, flexible dust wand, vacuum cleaner or compressed air to gently remove the dust.
- DO NOT immerse fan in water and never allow water to drip into the motor housing.
- DO NOT use gasoline, paint thinner or other chemicals to clean the fan.
- For storage, you may leave the fan assembled. Cover the fan to protect from dust and store in a cool, dry, place.

WARNING!

If the fan has any problems, please contact Sunpentown Customer Service at 909-468-5288.
DO NOT ATTEMPT TO OPEN OR REPAIR THE FAN YOURSELF. DOING SO COULD VOID THE WARRANTY AND CAUSE DAMAGE OR PERSONAL INJURY

SPECIFICATIONS

Noise level (High)	60 dB
Speed, RPM (High/Medium/Low)	1400 / 1200 / 900 (± 100)
Oscillation	70 degrees (± 5°)
Power input	120V / 60Hz / 0.4A
Wattage	45 W
Automatic shut-off timer	Maximum 2 hours
Fan speeds	3
Power cord length	5.9 ft
Unit dimension	12” diameter x 30” high
Package dimension (L x W x H)	8.6 x 7.5 x 30.9 in.
Net weight	11.5 lbs
Gross weight	12.5 lbs
Safety approval	ETL

Your Guarantee

If this product is found to be faulty as a result of faulty materials or workmanship within one year from date of purchase, it will be repaired free of charge.

This guarantee is subject to the following terms:

- Sunpentown must be notified of the fault.
- Proof of purchase must be presented to Sunpentown's nominated representative.
- The warranty will be void if the product if modified, misused or repaired by an unauthorized person.
- The warranty after repair will not be extended beyond the original one-year period.
- All replacement parts will be new or reconditioned.
- Parts, which are replaced, become the property of Sunpentown.
- The warranty applies for the use of the product in the USA only.

What is NOT COVERED:

- Warranty does not include freight charges.
- Incidental or consequential damage caused by possible defects with this product.
- Damage to product caused by improper power supply voltage, accident, fire, floods or acts of nature.
- Failure of product resulting from unauthorized modifications to the product.
- Improper installation or failure to perform the necessary maintenance.

This GUARANTEE is in addition to your Statutory Rights

SUNPENTOWN INTERNATIONAL INC.
21415 Baker Parkway, City of Industry, CA 91789-5236
Tel: 909-468-5288 · Fax: 909-468-5279
service@sunpentown.com
www.sunpentown.com